



# Automated Imaging and Analysis of 3D Tumor Spheroids, Cancer Stem Cell Colony Formations



## 3D Tumor Spheroids Functional Assays

The Celigo imaging cytometer has been developed to fully automate imaging and analysis of tumorspheres, embryoid bodies and cancer stem cell colonies. It has been used in the development of 3D tumor spheroid-based functional assays for target validation and drug evaluation.

Data courtesy of Dr. Maria Vinci, Cancer Research UK, Cancer Therapeutics Unit, The Institute of Cancer Research.




- Identify and count spheroids in flat or U-bottom wells.
- Eliminate cumbersome manual morphology measurements and improve data reproducibility.
- Monitor growth of spheroids over time.
- Screen numerous spheroid plates per day, 96, 384 well plates
- Scan an ultra-low adhesion 96-well plate in 8 minutes
- Measure viability using dual-fluorescence assays
- Multi-parameter analysis



**Counts / Size / Short & Long Diameter / Est. Volume / Perimeter / Area / More ...**

# Tumor Spheroid Growth Inhibition Assay

4-day old spheroids were treated with compounds for 72 hours. Drug induced concentration-dependent growth inhibition was obtained.




- Day 0 - 4: form spheroids
- Day 4 - 7: drug treatment
- Day 4 - 14: measure spheroid size





Vince et al. BMC Biology 2012, 10:29, March 2012

# Invasion into Matrigel Assay






- Day 0-4: form spheroids
- Day 4: add Matrigel to provide a semi-solid gel-like matrix
- Day 4-7: use Celigo imaging cytometer to determine the area occupied by individual cells or cell clusters



## Two-Fluorescence Viability Assay for 3D Tumor Spheroids

3D cultures were treated with multiple drugs (17-AAG, Paclitaxel, TMZ or Doxorubicin) and stained for viability after 21 days.

Live / dead stains used were Calcein AM (green), Propidium Iodide (red) to measure live and dead cells on days 4, 7, 10, 14, and 17. Plates containing spheroids were imaged on Celigo imaging cytometer.




- 17-AAG decreased sphere size and caused the most significant cell death
- Paclitaxel decreased sphere size but maintained a significant number of live cells
- Temozolomide caused no significant decrease in sphere size and did not cause cell death
- Doxorubicin decreased sphere size and caused significant cell death

Spheroid diameter (black) and total live fluorescent intensity (green) after drug treatment.

# Tumorsphere Formation Assay



These assays utilize Celigo's brightfield imaging mode and multiple quantification methods to obtain number and size of tumorspheres cultured in 96, 48, 24, 12, and 6-well microplates, as well as 60mm dish.



**Cellometer**<sup>®</sup>  
Simply Counted



**Celigo**<sup>®</sup>  
Image Cytometer



For more information, visit  
[www.nexcelom.com](http://www.nexcelom.com)

Contact us at:  
Nexcelom Bioscience  
360 Merrimack Street, Building 9  
Lawrence, MA 01843, USA

Email: [info@nexcelom.com](mailto:info@nexcelom.com)  
Phone: 978.327.5340  
Fax: 978.327.5341

[www.nexcelom.com/celigo](http://www.nexcelom.com/celigo)

Nexcelom products are for RESEARCH USE ONLY and are not approved for diagnostic or therapeutic use.  
© Copyright 2015 Nexcelom Bioscience LLC. All Rights Reserved.

1001266 RevC 3/15